




2. SGH-E770 Flow Chart of Troubleshooting

2-1.Baseband


2-1-1. Power ON










2-1-2. Initial












2-1-3. Sim Part








2-1-4. Microphone Part








2-1-5. Speaker Part






2-1-6. Camera Part







2-1-7. Mp3 Display Part




2-2.RF


2-2-1. EGSM RX






2-2-2. DCS RX






2-2-3. PCS RX



2-2-4. EGSM TX



2-2-5. DCS & PCS TX

